

# HOJDÁVAK

MAXI

## textile hammock for adults

en

### INSTRUCTIONS FOR USE

Dear Customer,

We are delighted that you have chosen our **Hojdakov Maxi** hammock, designed for teenagers and adults. The hammock can hold a maximum **120 kg**. This a product, based on our own design, that we have made with love in the Czech Republic in partnership with Czech manufacturers and suppliers. **We use only high-quality and non-toxic materials.** By purchasing this product, you are also supporting sheltered workshops.

Hojdakov Maxi relaxes your body and soul. Thanks to the **80cm bar**, it offers sufficient inner space while respecting the smaller space of some homes. The felt makes sure that people of all ages will enjoy lying down in the hammock.

Thank you for purchasing Hojdakov!

The Hojdakov Team

ČESKÁ VERZE KE STAŽENÍ NA:  
[WWW.HOJDAVAK.CZ](http://WWW.HOJDAVAK.CZ)

DEUTSCHE VERSION ZUM DOWNLOAD:  
[WWW.HOJDAVAK.DE](http://WWW.HOJDAVAK.DE)



## INTENDED USE

The Hojdavak Maxi hammock is designed to be used for swinging, sitting and lying down. Any methods and conditions of use other than those specified by us are not permitted. The maximum bearing capacity is 120 kg.

## SAFETY ALERT

- **Carefully read the instructions for use and use the product according to the instructions given** – any modifications and changes to the product that have a negative impact on safety and health are not permitted. Do not hang the hammock near a fire or other heat sources.
- **Do not exceed the permitted bearing capacity of 120 kg** – the manufacturer is not liable for any accidents.
- **Do not sit on the wooden bar.**
- **Regularly check the condition of the ropes used** – they must be in perfect condition and free of mechanical wear and tear. If damage is detected, no matter how little, replace the rope immediately!
- **Regularly check the strength of the suspension** – the ceiling screw, separate stand. Position the hammock only in places that will safely support the load. Avoid gypsum board ceilings or other similar types of wall-covering. Consult an anchoring specialist on how to suspend the hammock safely. Check the strength of the screws and brackets by conducting a load test using your own weight.
- **Packaging** – after the product has been unpacked, plastic bags and other packaging must be kept out of reach of children under 3 years of age.

## CONTENTS OF PACKAGING

- Textile bag with an Öko-Tex Standard 100 health certificate
- Felt, thickness 4 mm, size 40 × 140 cm, to be inserted into the pocket
- Wooden spacer made of hard beech – 80 cm in length – not painted or varnished
- 2× wooden support bars, hard beech – 40 cm in length – not painted or varnished
- Snap-hook
- Polyamide rope with a 7 mm diameter cable
- Pillow with a zip pillowcase (30 × 50 cm)
- Instructions for use
- Non-woven fabric case

## MAINTENANCE

The textile bag can be washed at 40 °C and dried on a moderate setting. The felt can only be washed by hand. If used outdoors, we recommend varnishing or painting the wooden parts. Protect the hammock from rain, extreme weather and direct sunlight. The product life is at least 2 years.

## WHERE TO HANG IT

For children, we recommend hanging it in the living room so that parents can keep an eye on them. Older children may have the hammock suspended directly in their room. A space where the whole family spends much of their time is ideal. Another suitable place for suspending the hammock is a gazebo or a tree in the garden. Basically, wherever you like to rest.

## HOW TO HANG IT

The hammock can be suspended using any secure anchor with a minimum bearing capacity of 200 kg, such as a screw installed in the ceiling, or via any other fixed element that can support the load (e.g. stairs, beams, tree branch, etc.).

The suspension point should be at least 200 cm above the ground. The height of the swing is approx. 165 cm (see Figure 1). Higher positioning of the suspension point will require an extra rope to extend the length. If it is to be used by very young children, suspend it just above the ground. Tie the extension rope so that it does not fray at the attachment point (see Figure 2).

Consult an anchoring specialist on the safe installation of the anchor. There are many ways to do this, depending on the possibilities available and your preferences. Our suspension methods can be found in the e-shop under "Hammock Suspension".





Figure 1



Figure 2



## ASSEMBLY

- 1) Decide **where and how to hang the hammock** and install the anchor.
- 2) **Take the textile bag**, spread it out and place the felt in the pocket in the middle of the fabric. For more comfortable seating, the front  $\frac{1}{3}$  of the bag can be folded under the bag and the full length can be used, for example, for children or as a footrest.
- 3) Take the wooden bar with the sidewalls tied and use the snap-hook to hang it in the prepared place. Add the side wooden supports into the side folds/tunnels in the textile bag and secure with the rope.
- 4) **Important! Check** that everything is installed correctly.
- 5) Regularly **check that the hanging is firm** and that all parts of the hammock are properly installed and closed.

## PRODUCT DISPOSAL

If the hammock becomes irreparably damaged or reaches the end of its useful life, it must be dismantled and separated into individual parts, components and materials. These are disposed of in accordance with laws and regulations applicable at the time of disposal.

Manufacturer: Petra Holá  
Company Reg. No 68971575

Downloadable instructions:  
[www.hojdava.cz](http://www.hojdava.cz)