

HOJDÁVAK

JUNIOR

textile hammock for small children from 3 years of age

en

INSTRUCTIONS FOR USE

Dear Customer, Dear Parent,

We are delighted that you have chosen our **Hojdakov Junior** textile hammock, designed for small children from 3 years of age. The hammock can hold a maximum weight of **40 kg**. This is a product, based on our own design, that we have made with love in the Czech Republic in partnership with Czech manufacturers and suppliers. **We use only high-quality and non-toxic materials.** By purchasing this product, you are also supporting sheltered workshops.

The Hojdakov Junior hammock is designed for both relaxation and active fun.

Thank you for your purchase!

The Hojdakov Team

ČESKÁ VERZE KE STAŽENÍ NA:
WWW.HOJDAVAK.CZ

DEUTSCHE VERSION ZUM DOWNLOAD:
WWW.HOJDAVAK.DE



INTENDED USE

The Hojdavak Junior hammock is designed to be used for swinging, sitting and lying by small children from 3 years of age. Only use this product according to methods and conditions specified us!

SAFETY ALERT

- **Carefully read the instructions for use and use the product according to the instructions given** – any modifications and changes to the product that have a negative impact on safety and health are not permitted. Do not hang the hammock near a fire or other heat source.
- **Do not leave children unattended.**
- **Do not sit on the wooden bar.**
- **Do not exceed the permitted bearing capacity** – the manufacturer is not liable for any accidents.
- **Regularly check the condition of the ropes used** – they must be in perfect condition and free of mechanical wear and tear. If damage is detected, no matter how little, replace the rope immediately!
- **Regularly check the strength of the suspension** – the ceiling screw, the separate stand and/or other components. Position the swing only in places that will safely support the load. Avoid gypsum board ceilings and other similar types of wall-covering. Consult an anchoring specialist on how to suspend the hammock safely. Check the strength of the screws and brackets by conducting a load test using your own weight.
- **Packaging** – after the product has been unpacked, plastic bags and other packaging must be kept out of reach of children under 3 years of age.

CONTENTS OF PACKAGING

- Textile bag with an Öko-Tex Standard 100 health certificate
- Fleece blanket used to fill the middle pocket
- Wooden spacer made of hard beech – 70 cm in length – not painted or varnished
- 2× wooden support bars, hard beech – 35 cm in length – not painted or varnished
- Snap-hook
- Polyamide rope with 5 mm diameter cable
- Instructions for use
- Textile case

MAINTENANCE

The textile bag can be washed at 40 °C and dried on a moderate setting. If used outdoors, we recommend varnishing or painting the wooden parts. Protect the swing from rain, extreme weather and direct sunlight. This product has a useful life of at least 2 years.

WHERE TO HANG IT

Considering the low age group for which the Hojdavak Junior is designed, place it somewhere you spend a lot of your time, i.e. near the kitchen or in the living room. Children like to experiment with the hammock and it is advisable to supervise them while they are playing.

HOW TO HANG IT

The hammock can be suspended in any secure anchorage point, such as a ceiling screw or on any other fixed element that can support the load (e.g. stairs, beams, tree branch, etc.). The point from which it is suspended should be at least 170 cm above the ground. The hammock is approx. 160 cm high (see Figure 1). If suspended from a higher point, an extra rope is required to extend the length. Hang the hammock just above the ground for the youngest children. The space above the ground should be at least 5 cm to enable the comfortable swinging of small children. Consult an anchorage specialist for safe installation of the anchor. There are many ways to do this, depending on the possibilities available to you and your preferences. Our suspension methods can be found in the e-shop under "Hammock Suspension". Tie the extension rope so that it does not fray at the attachment point (see Figure 2).




Figure 1



Figure 2



ASSEMBLY

- 1) Decide **where and how to hang the hammock** and install the anchor.
- 2) Take the textile bag, spread it out and place the fleece blanket in the pocket in the middle of the fabric. The blanket is put only in the back $\frac{2}{3}$ of the pocket. For more comfortable seating, the front $\frac{1}{3}$ of the bag can be folded under the bag and the full length can be used as a footrest for children lying in it.
- 3) Take the wooden bar with the side pieces tied to it and use the snap-hook to hang it in the prepared place. Next, slide the side wooden supports into the side cross-bars and secure with a rope, making a loop or tying a knot on it.
- 4) Important! **Check that everything is installed correctly.**
- 5) Regularly check that the suspension is tight and that all parts of the swing are properly installed and closed.

PRODUCT DISPOSAL

If the product becomes irreparably damaged or reaches the end of its useful life, it must be dismantled and separated into its individual parts, components and materials. These are then disposed of in accordance with laws and regulations applicable at the time of disposal.

Manufacturer: Petra Holá
Company Reg. No 68971575

Downloadable instructions:
www.hojdavak.cz